

MAGNA-SAFE	Mixers	Bulletin 01-050 10/6/03	Page 1 of 1
------------	--------	----------------------------	----------------

INITIAL INSPECTION

Step 1: Inspect crates. Upon receipt, inspect all crates and equipment for shipping damage. Report shipping damage to Magna-Sage International. A claim should be filed immediately with the carrier involved.

Step 2: Uncrate. Check the contents. Do not uncrate the unit until you have read the Installation section of this manual and looked at the assembly drawing. Be careful in uncrating and handling. Do not discard the crating without carefully making sure that all the agitator parts have been removed. Correct assembly of this unit requires referring to both the unit assembly drawing and this manual.

Step 3: Questions? Call Magna-safe. If the shipment is not complete or you do not understand what you have received, please contact Magna-Safe International.

Magna-Safe International, Inc.

P.O. Box 447
Old Bridge, NJ 08857-0447

Toll Free: (866) 626-8885
Telephone: (732) 603-2188
Fax:(732) 972-0393
email: info@magnasafe.com